

## **Veto/Evo System Draining Instructions.**

Use these if the alarm system has been spiked.

1. Remove lid from main alarm unit.
2. Remove internal battery from PCB.
3. Remove alarm inline fuse
4. Unplug PCB from alarm loom

**Leave these parts out over a period of at least 6 hours, to allow the system to drain completely.**

With the bikes battery still in place and fully charged.

1. Plug PCB onto loom and reinstall.
2. Replace In-Line fuse.
3. The alarm will sound for a period of approx. 30 seconds.
4. Allow the system to reset itself.
5. Replace internal battery onto PCB.
6. Make sure all connections are complete.
7. Re-Align the remote – *Press and hold both buttons for a period of 5 seconds, then press the circle button.*